

## STR-DN1030



### GUI Menu List/Liste des menus de l'interface utilisateur/Lista de menús de la interfaz gráfica de usuario/Lista do Menu GUI

<p>Input</p>	<p>▶ BD/DVD SA-CD/CD</p>	<p>GAME</p>	<p>SAT/CATV</p>	<p>VIDEO 1</p>	<p>VIDEO 2</p>	<p>TV</p>	<p>[OPTIONS] Input Assign* Name Input</p>
<p>Music</p>	<p>▶ iPod/iPhone</p>	<p>USB</p>	<p>AirPlay</p>	<p>HOME NETWORK</p>	<p>SEN</p>	<p>BLUETOOTH</p>	<p>[OPTIONS] System GUI* iPod* Function List*</p>
<p>Video</p>	<p>▶ iPod/iPhone</p>						<p>[OPTIONS] System GUI* iPod*</p>
 FM  AM	<p>▶ Auto Tuning</p>	<p>Direct Tuning</p>	<p>Preset 1 ... 30</p>				<p>[OPTIONS] Auto Tuning Direct Tuning Name Input*</p>
<p>Settings</p>	<ul style="list-style-type: none"> <li>▶ Auto Cal.               <ul style="list-style-type: none"> <li>Start</li> <li>Cal. Type                   <ul style="list-style-type: none"> <li>Full Flat</li> <li>Engineer</li> <li>Front Reference</li> <li>Off</li> </ul> </li> </ul> </li> <li>Speaker               <ul style="list-style-type: none"> <li>SP Pattern</li> <li>SB Assign*</li> <li>Manual Setup                   <ul style="list-style-type: none"> <li>Lvl</li> <li>Dist</li> <li>Size*</li> </ul> </li> <li>Crossover Freq*</li> <li>Test Tone</li> <li>D.Range Comp</li> <li>Distance Unit</li> </ul> </li> <li>Surround               <ul style="list-style-type: none"> <li>Sound Field                   <ul style="list-style-type: none"> <li>Effect*</li> </ul> </li> </ul> </li> <li>EQ               <ul style="list-style-type: none"> <li>Gain Adjust (Bass/Treble)</li> </ul> </li> <li>Audio               <ul style="list-style-type: none"> <li>D.L.L.</li> <li>A/V Sync</li> <li>Dual Mono</li> </ul> </li> <li>HDMI               <ul style="list-style-type: none"> <li>Ctrl for HDMI</li> <li>Pass Through</li> <li>Audio Out</li> </ul> </li> <li>Network               <ul style="list-style-type: none"> <li>Settings                   <ul style="list-style-type: none"> <li>Wireless LAN Settings</li> <li>Wired LAN Settings</li> </ul> </li> <li>Information</li> <li>PARTY STREAMING</li> <li>Access Settings                   <ul style="list-style-type: none"> <li>Auto Access</li> <li>Control Device</li> </ul> </li> <li>Media Remote Device Registration</li> <li>Registered Media Remote Devices</li> <li>Device Name</li> <li>Network Standby</li> <li>Software Update</li> </ul> </li> <li>Bluetooth               <ul style="list-style-type: none"> <li>Pairing</li> <li>BT Standby*</li> <li>Clear History*</li> <li>Address Info</li> </ul> </li> <li>System               <ul style="list-style-type: none"> <li>Auto Standby</li> </ul> </li> </ul>						<p>* Menu parameters displayed on the TV screen vary, depending on the current settings or the status of the selected icon.</p> <p>* Les paramètres de menu affichés sur l'écran du téléviseur varient selon les réglages actuels ou l'état de l'icône sélectionnée.</p> <p>* Los parámetros del menú que se muestran en la pantalla del televisor varían dependiendo de los ajustes actuales o del estado del icono seleccionado.</p> <p>* Os parâmetros do menu que aparecem na tela do televisor variam dependendo dos ajustes atuais ou do estado do ícone selecionado.</p>