

Switch Configurations

Stand Alone (Presenter Computer)

Setup 1 = IN-2 to Out-B (Video and Onkye sound)

Setup 2 = IN-2 to Out-A (Video only)

Stand Alone (Visitor Pass through Computer)

Setup 1 = IN-4 to Out-B (Video and Onkye sound)

Setup 2 = IN-4 to Out-A (Video only)

Stand Alone Docucam

Setup 1 = IN-4 to Out-B

Setup 2 = IN-4 to Out-A

Life Size

Setup 1 = IN-2 to Out-A (normal operation)

Setup 2 = IN-4 to Out-A (Docucam operation)

Hybrid Host and Presenter Computers

Setup 1 = IN-1 to Out-A (For Host)

Setup 2 = IN-1 to Out-B (For Host)

Additional Optional setups for Setup 1 and 2

Setup A = IN-2 to Out-C (For Presenter's Life Size Cameras)

Setup B = IN-4 to Out-C (For Presenter's Docucam)