



Master Power  
Switch

**TA1 Master Power switch for podium area electronics – laptop, docucam, guest power strip.**



**TA1 Video Selector Switch for images routed to the projector from the podium area.**




**New power strip on docucam cart. Leave switch on, controlled by Master Power Switch on Surge Protector mounted on wall. Docucam plugged in here. Use this strip to power guest laptops.**





**Guest Laptop / Device HDMI cable, hanging on hook on rear of Docucam Cart.**

TA1 Switch on Wall adjacent to laptop cart to control inputs to projector. Push silver switch to cycle thru inputs; handshaking takes 8 – 10 seconds. One push moves to next input; must cycle thru all to get back to #1. Green LED illuminates for selected input. Red – steady, when handshake is complete. If 2 is selected, must push 3 times to return to #1; wait 10 seconds for handshake to complete.



- 1 - OLLI Laptop
- 2 - Document Camera
- 3 - Guest HDMI Cable
- 4 – Unused at this time

Note: check <Windows><P> on 'Duplicate' if no image from laptop